BMW X3M VALVE CONTROL INSTALLATION

Open the boot and look to the right hand side

Remove the panel and liner to gain access to the cavity behind, here you will find a gromet which can be used to run the cable, the gromet will need to be cut to allow the cable to pass through, then it can be closed using silicone afterward. Secure the module in place somewhere safe and cable tie wires to keep tidy.





MILLTEK



