SYSTEM NO.	SSXRN301
DESCRIPTION	Hi-Flow Sports Cat
NOTES	For fitment to Milltek cat-back system ONLY. Requires a Stage 2 ECU remap

PARTS REQUIRED

PART NO.	DESCRIPTION	QUANTITY	IN PACKAGE
MSRN108	**Hi-flow Sports Catalyst Assembly**	**1**	

TECHNICAL INFORMATION

NOTES	For fitment to Milltek cat-back system ONLY. Requires a Stage 2 ECU remap

1. Remove rear diffuser,
2. Cut the oe exhaust at both cut off points (See photos 1 and 2,
3. Remove both rear hanging brackets with silencer,
4. Unbolt the centre pipe bracket from exhaust and remove remembering to support the oe cat,
5. Fit the MSRN109 using the adaptor and clamps as provided,
6. Install the 2 rear hanging brackets to the vehicle and secure,
7. Fit the MSRN110,
8. Fit the MSRN111,
9. Adjust parts as required for correct fitment and secure using MSRN112 brace bar and fully tighten all clamps and brackets,
10. Re-fit rear diffuser and check trims for correct clearance.



