SYSTEM NO.	**SSXFD226 + SSXFD229**

VEHICLES	YEARS
FORD MUSTANG 5.0 V8 GT (FASTBACK)	2015 TO 2018

NOTES	Insert

TECHNICAL INFORMATION

NOTES	Insert

Can Bus Installation

From the loom on the controller connect as follows on the rear of OBD2 Port: -



Can High = Pin 20 Blue Wire
Can Low = Pin 19 White Wire

The wire colours from the loom on the controller will be as follows: -

CAN-HIGH Yellow/White
CAN-LOW Yellow

CAN-HIGH Green/White
CAN-LOW Green

CAN-HIGH Red/Blue
CAN-LOW Red

CAN-HIGH Yellow/Red
CAN-LOW Yellow/Brown

CAN-HIGH Orange/Black
CAN-LOW Orange/Brown

Power Connection: -

In the rear trunk connect the Brown wire to a suitable earth.

The red wire needs to be connected to a 12v Ignition Swtiched Live, under the rear seat the on the left as shown below is a suitable connection point for this:



Connection to the Valve Motors: -

The two 3 wire connections to the valves need to be connected as follows: -

Pin 1 = Red or Blue
Pin 2 = Yellow or Yellow & Green
Pin 3 = Red or Brown



